


BLOWER MOTOR REMOVAL

AC08K-01

1. REMOVE GLOVE COMPARTMENT DOOR
(See page [BO-47](#))



2. REMOVE BLOWER MOTOR
 - (a) Disconnect the connector.
 - (b) Remove the 3 screws and motor.