

DISASSEMBLY


HINT:

A bolt without a torque specification is shown in the standard bolt chart (see page [SS-2](#)).

1. w/o Power window:

REMOVE REGULATOR HANDLE

Pull off the snap ring with a cloth and remove the regulator handle and plate.




2. REMOVE INSIDE HANDLE BEZEL

- Remove the screw.
- Using a screwdriver, remove the inside handle bezel as shown in the illustration.

HINT:

Tape the screwdriver tip before use.



3. w/ Power window:

REMOVE POWER WINDOW SWITCH

- Using a screwdriver, remove the power window switch.

HINT:

Tape the screwdriver tip before use.

- Disconnect the connectors.

4. w/ Courtesy light:

REMOVE COURTESY LIGHT

- Using a screwdriver, remove the courtesy light.

HINT:

Tape the screwdriver tip before use.

- Disconnect the connector.

5. w/o Courtesy light:

REMOVE COURTESY LIGHT COVER

Using a screwdriver, remove the courtesy light cover.

HINT:

Tape the screwdriver tip before use.

6. w/ Tweeter speaker:

REMOVE TWEETER SPEAKER

- Using a screwdriver, remove the tweeter speaker cover.

HINT:

Tape the screwdriver tip before use.


- Disconnect the connector.
- Remove the 3 screws and tweeter speaker.

7. REMOVE DOOR TRIM

- (a) Remove the 2 caps and 2 screws.
- (b) Insert a screwdriver between the door trim and door panel to remove the door trim.

HINT:

Tape the screwdriver tip before use.




- (c) Pull the door trim upward to remove it.

8. REMOVE DOOR ASSIST GRIP

Remove the 2 screws and door assist grip from the door trim.

9. REMOVE INNER WEATHERSTRIP**10. REMOVE LOWER WEATHERSTRIP****11. REMOVE INSIDE HANDLE**

- (a) Remove the screw.
- (b) Slide the inside handle backward to remove it.



- (c) Disconnect the 2 cables from the inside handle as shown in the illustration.

12. REMOVE SERVICE HOLE COVER


- (a) Disconnect the clamps and connector.
- (b) Remove the service hole cover.

13. REMOVE SPEAKER


- (a) Disconnect the connector.
- (b) Remove the 3 screws and speaker.

14. REMOVE OUTSIDE REAR VIEW MIRROR


- (a) w/ Remote control:
Disconnect the connector.
- (b) Remove the 3 screws and outside rear view mirror.

**15. REMOVE DOOR BELT MOULDING**


Using a moulding remover, remove the door belt moulding.

16. REMOVE DOOR GLASS RUN**17. REMOVE FRONT LOWER FRAME**

Remove the 2 bolts, nut and front lower frame as shown in the illustration.

**18. REMOVE REAR LOWER FRAME**


Remove the bolt, nut and rear lower frame as shown in the illustration.

**19. REMOVE DOOR GLASS**


- (a) Open the door glass until the bolts appear in the service hole.
- (b) Remove the 2 bolts and door glass.

NOTICE:

Do not damage the door glass.

**20. REMOVE WINDOW REGULATOR**

- (a) w/ Power window:
Disconnect the connector.
- (b) w/ Power window:
Remove the 5 bolts, nut and window regulator.
- (c) w/o Power window:
Remove the 4 bolts, nut and window regulator.
- (d) Remove the window regulator through the service hole.

**21. REMOVE DOOR LOCK**

- (a) Disconnect the 2 links from the outside handle and door lock cylinder.
- (b) w/ Power door lock:
Disconnect the connector and remove the bolt.
- (c) Using a torx® socket wrench, remove the 3 torx® screws.

Torx® socket wrench:

T30 (Part No. 09042-00010 or locally manufactured tool)

22. REMOVE OUTSIDE HANDLE WITH DOOR LOCK CYLINDER

- (a) Remove the 2 bolts and outside handle together with the door lock cylinder.
- (b) Remove the door lock cylinder from the outside handle.