

INSTALLATION

1. INSTALL TAIL GATE

- (a) Using a torx® socket wrench (T40), install the tail gate hinges to the tail gate with the 4 screws.


Torque: 17 N·m (178 kgf-cm, 13 ft-lbf)

- (b) Install the tail gate to the body with the 2 bolts.

Torque: 17 N·m (178 kgf-cm, 13 ft-lbf)

NOTICE:

Be careful not to drop the tail gate.



2. INSTALL TAIL GATE CABLE

- (a) Install the tail gate cable and gate side shaft to the tail gate.

Torque: 14 N·m (143 kgf-cm, 10 ft-lbf)

- (b) Install the tail gate cable and deck side shaft to the body.


Torque: 14 N·m (143 kgf-cm, 10 ft-lbf)

- (c) Use the same procedures described above to the other side.

3. INSTALL TAIL GATE LOCK STRIKER

Using a torx® socket wrench (T40), install the 2 tail gate lock strikers with the 4 screws.

Torque: 13 N·m (133 kgf-cm, 10 ft-lbf)



4. INSTALL TAIL GATE HANDLE ASSEMBLY


Install the tail gate handle assembly with the 2 bolts.

Torque: 5.5 N·m (56 kgf-cm, 49 in.-lbf)

5. INSTALL TAIL GATE LOCK

- (a) Using a torx® socket wrench (T40), install the 2 tail gate locks with the 4 screws.

Torque: 12.5 N·m (128 kgf-cm, 9 ft-lbf)



- (b) Connect one end of the tail gate lock link to the tail gate lock and another end to the tail gate handle assembly.

6. INSTALL SERVICE HOLE COVER

Using a torx® socket wrench (T30), install the service hole cover with the 8 screws.

7. INSTALL TAIL GATE PROTECTOR (See page [BO-68](#))