

REMOVAL


NOTICE:

- If the wiring connector of the SRS is disconnected with the ignition switch in the ON position, DTCs will be recorded.
- Never use SRS parts from another vehicle. When replacing the parts, replace them with new ones.
- Never reuse a seat position sensor assembly if the airbag has previously deployed in a collision.

1. PRECAUTION (SEE PAGE [RS-1](#) AND [RS-3](#))
2. DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL

Wait for 90 seconds after disconnecting the cable to prevent the airbag working.

3. Separate type:
Split type:
REMOVE FRONT SEAT ASSEMBLY LH
(SEE PAGE [BO-141](#))
4. Bench type:
REMOVE FRONT SEAT ASSEMBLY
(SEE PAGE [BO-166](#))
5. Separate type (Manual adjuster):
Split type:
REMOVE VERTICAL ADJUSTER HANDLE
(SEE PAGE [BO-156](#))
6. Separate type (Manual adjuster):
Split type:
REMOVE SEAT CUSHION OUTER SHIELD
(SEE PAGE [BO-156](#))
7. Separate type (Power adjuster):
REMOVE SLIDE KNOB AND RECLINING KNOB
(SEE PAGE [BO-142](#))
8. Separate type (Power adjuster):
REMOVE SEAT CUSHION LOWER SHIELD, SEAT CUSHION OUTER SHIELD AND SEAT CUSHION INNER SHIELD (SEE PAGE [BO-142](#))



9. REMOVE SEAT POSITION SENSOR ASSEMBLY PROTECTOR

Remove the seat position sensor assembly protector from the seat position sensor assembly.

10. REMOVE SEAT POSITION SENSOR ASSEMBLY

- (a) Disconnect the connector from the seat position sensor assembly.
- (b) Using a torx® socket wrench (T30), remove the torx® screw and the seat position sensor assembly.