


## REMOVAL

### NOTICE:

- If the wiring connector of the SRS is disconnected with the ignition switch in the ON position, DTCs will be recorded.
  - Never use SRS parts from another vehicle. When replacing the parts, replace them with new ones.
  - Never reuse an occupant classification ECU if an airbag has previously deployed in a collision.
1. **PRECAUTION (SEE PAGE RS-1 AND RS-3)**
  2. **When only occupant classification ECU is removed: REGISTRATION (SEE PAGE DI-1828-1)**
  3. **DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL**

Wait for 90 seconds after disconnecting the cable to prevent the airbag working.

4. **Bench type:**  
**REMOVE FRONT SEAT ASSEMBLY**  
(SEE PAGE BO-165)
5. **Split type:**  
**REMOVE FRONT SEAT ASSEMBLY**  
(SEE PAGE BO-188)



6. **REMOVE OCCUPANT CLASSIFICATION ECU**
  - (a) Disconnect the connector from the occupant classification ECU.
  - (b) Remove the 2 bolts and the occupant classification ECU.