



INSPECTION

INSPECT STABILIZER BAR LINK

Rotate the ball joint stud in all directions.

If it does not move smoothly and freely, replace the stabilizer link.