

INJECTOR

SF1YF-01

ON-VEHICLE INSPECTION

1. REMOVE V-BANK COVER
 2. REMOVE AIR CLEANER (See page [EM-62](#))
 3. REMOVE INTAKE AIR SURGE TANK (See page [EM-62](#))
 4. INSPECT INJECTOR RESISTANCE
 - (a) Disconnect the 6 injector connectors.
 - (b) Using an ohmmeter, measure the resistance between the terminals.
Resistance: 11.6 to 12.4 Ω at 20°C (68°F)
- If the resistance is not as specified, replace the injector.
- (c) Reconnect the 6 injector connectors.
 5. INSTALL INTAKE AIR SURGE TANK (See page [EM-89](#))
 6. INSTALL AIR CLEANER (See page [EM-89](#))
 7. INSTALL V-BANK COVER