



## INSTALLATION

### 1. INSTALL GENERATOR

- (a) Install the generator with the 2 bolts.  
**Torque: 43 N·m (438 kgf·cm, 32 ft·lbf)**



- (b) Install the wire harness clamp bracket with the 2 bolts.  
**Torque: 8.0 N·m (82 kgf·cm, 71 in·lbf)**



- (c) Connect the wire harness.  
(1) Connect the wire harness to the terminal B and install the nut.  
**Torque: 9.8 N·m (100 kgf·cm, 7 ft·lbf)**  
(2) Connect the connector to the generator assy.  
(3) Install the wire harness stay with the bolt.  
**Torque: 8.0 N·m (82 kgf·cm, 71 in·lbf)**

### 2. INSTALL BATTERY

### 3. INSTALL FAN AND GENERATOR V BELT (See page [EM-89](#))

4. **INSTALL ENGINE UNDER COVER SUB-ASSY NO.1**  
Install the engine under cover sub-assy No. 1 with the 4 bolts.  
**Torque: 29 N·m (296 kgf·cm, 21 ft·lbf)**

### 5. INSTALL V-BANK COVER

- Install the V-bank cover with the 2 nuts.  
**Torque: 9.8 N·m (100 kgf·cm, 87 in·lbf)**