



BLOWER RESISTOR INSPECTION

1. REMOVE GLOVE COMPARTMENT PARTS
2. REMOVE LOWER NO. 2 FINISH PANEL
3. REMOVE LOWER CENTER COVER
4. REMOVE LOWER LH FINISH PANEL
5. REMOVE LOWER COVER (See page [BO-111](#))
6. REMOVE NO. 4 HEATER TO REGISTER DUCT




7. REMOVE BLOWER RESISTOR
 - (a) Disconnect the connector.
 - (b) Remove the 2 screws and blower resistor.



8. INSPECT BLOWER RESISTOR RESISTANCE

Tester connection	Condition	Specified condition
1-4	Constant	$3.3 \pm 0.2 \Omega$
1-3	Constant	$1.9 \pm 0.1 \Omega$
1-2	Constant	$2.9 \pm 0.2 \Omega$

If resistance is not as specified, replace the blower resistor.



9. INSTALL BLOWER RESISTOR
 - (a) Install the blower resistor with the 2 screws.
 - (b) Connect the connector.

10. INSTALL NO. 4 HEATER TO REGISTER DUCT
11. INSTALL LOWER COVER
12. INSTALL LOWER LH FINISH PANEL
13. INSTALL LOWER CENTER COVER
14. INSTALL LOWER NO. 2 FINISH PANEL
15. INSTALL GLOVE COMPARTMENT PARTS
(See page [BO-120](#))