


REMOVAL

REMOVE PROPELLER SHAFT

- Place matchmarks on the differential and propeller shaft flanges.
- Except Double-Cab model:
Remove the 4 bolts, washers and nuts.
- Double-Cab model:
Remove the 4 nuts and washers.
- Remove the 2 mounting bolts and center support bearing from the frame crossmember.
- Pull out the propeller shaft yoke from the transmission.



- Insert SST in the transmission to prevent oil leakage.
SST 09325-40010