


# INSPECTION

## 1. INSPECT FOG LIGHT SWITCH CONTINUITY

Switch Position	Tester Connection	Specified Condition
OFF	10 – 11	No continuity
ON	10 – 11	Continuity


If the continuity is not as specified, replace the switch.



## 2. Double cab: INSPECT FOG LIGHT RELAY CONTINUITY

Tester Connection	Specified Condition
3 – 5	No continuity
3 – 5	Continuity (When battery voltage is applied to terminals 1 and 2)

If the continuity is not as specified, replace the switch.



## 3. Except double cab: INSPECT FOG LIGHT RELAY (Marking: FOG) CONTINUITY

Tester Connection	Specified Condition
3 – 5	No continuity
3 – 5	Continuity (When battery voltage is applied to terminals 1 and 2)

If the continuity is not as specified, replace the relay.