



INSTALLATION

1. **INSTALL FUEL PRESSURE PULSATION DAMPER**
 - (a) Apply a light coat of spindle oil or gasoline to a new O-ring and install it to the fuel pressure pulsation damper.
 - (b) Install the fuel pressure pulsation damper to the fuel delivery pipe.
 - (c) Install the clip.
2. **INSTALL V-BANK COVER**
3. **CHECK FOR FUEL LEAKS**