



INSTALLATION

1. INSTALL WATER INLET W/THERMOSTAT

- (a) Install a new gasket to the water inlet w/ thermostat.
- (b) Install the water inlet w/ thermostat with the 3 nuts.

Torque: 9.0 N·m (92 kgf·cm, 80 in·lbf)

2. CONNECT RADIATOR OUTLET, NO.2 HOSE CLAMP OR CLIP

3. ADD ENGINE COOLANT (See page [CO-2](#))

4. CHECK FOR ENGINE COOLANT LEAKS

5. INSTALL V-BANK COVER

Install the V-bank cover with the 2 nuts.

Torque: 9.8 N·m (100 kgf·cm, 87 in·lbf)