


- * 1 : 6 Speaker
- * 2 : 8 Speaker w/ Navigation System
- * 3 : 8 Speaker w/o Navigation System



Illumination (Double Cab)

: Parts Location

Code		See Page		Code		See Page		Code		See Page	
A18		72		I24	A	73		R3		75	
B9	A	72		J45		74		R14	C	75	
B10	B	72		J46		74		R15	D	75	
C8		72		J57		74		R27	E	75	
C11	A	72		J58		74		R28	F	75	
C15		72		M5		75		S11		75	
C16		72		O8		76		S12		75	
F13		70		R1	A	75					
G3		73		R2	B	75					

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1B	49	Cowl Wire and Driver Side J/B (Lower Finish Panel)
1E		
1F		
1G		
1H		
1L	49	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
1M	49	Roof Wire and Driver Side J/B (Lower Finish Panel)
4A	54	Cowl Wire and Sub J/B No.4 (Upper the Accelerator Pedal)
4B		
4C		
4D		
4E		

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IC5	92	Cowl Wire and Roof Wire (Left Side of Instrument Panel)
ID2	92	Cigarette Lighter Wire and Cowl Wire (Instrument Panel Brace LH)

: Ground Points

Code	See Page	Ground Points Location
IN	92	Right Kick Panel
IO	92	Left Kick Panel

