

INSTALLATION

1. REMOVE HEAT INSULATOR

- (a) Install the No.1 heat insulator with the 5 bolts.

Torque: 5.0 N·m (51 kgf·cm, 44 in.-lbf)

- (b) Install the No.2 heat insulator with the 4 bolts.

Torque: 5.0 N·m (51 kgf·cm, 44 in.-lbf)

- (c) Install the No.3 heat insulator with the 3 bolts.

Torque: 5.0 N·m (51 kgf·cm, 44 in.-lbf)

- (d) Install the No.4 heat insulator with the 2 bolts.

Torque: 7.0 N·m (71 kgf·cm, 62 in.-lbf)

2. INSTALL EXHAUST TAIL PIPE

Install the 3 rings and exhaust tailpipe.

3. INSTALL CENTER EXHAUST PIPE

- (a) Install the 2 rings and center exhaust pipe.

- (b) Install a new gasket and connect the center exhaust pipe to the exhaust tailpipe with a new clamp.

Torque: 32 N·m (326 kgf·cm, 24 ft-lbf)

4. INSTALL LH FRONT EXHAUST PIPE

- (a) Install a new gasket and ring to the LH front exhaust pipe.

- (b) Install the LH front exhaust pipe to the exhaust manifold with 3 new nuts.

Torque: 62 N·m (632 kgf·cm, 46 ft-lbf)

5. INSTALL RH FRONT EXHAUST PIPE

- (a) Install a new gasket to the RH front exhaust pipe.

- (b) Install the RH front exhaust pipe to the exhaust manifold with 3 new nuts.

Torque: 62 N·m (632 kgf·cm, 46 ft-lbf)

6. CONNECT EXHAUST CENTER PIPE

- (a) Install a new gasket and connect the RH front exhaust pipe with the 2 bolts.

Torque: 48 N·m (489 kgf·cm, 35 ft-lbf)

- (b) Install a new gasket and connect the LH front exhaust pipe with the 2 bolts.

Torque: 48 N·m (489 kgf·cm, 35 ft-lbf)

7. INSTALL HEATED OXYGEN SENSOR (BANK2)

- (a) Install the heated oxygen sensor.

Torque: 44 N·m (450 kgf·cm, 33 ft-lbf)

- (b) Connect the heated oxygen sensor connector.

8. INSTALL HEATED OXYGEN SENSOR (BANK1)

- (a) Install the heated oxygen sensor.

Torque: 44 N·m (450 kgf·cm, 33 ft-lbf)

- (b) Connect the heated oxygen sensor connector.