



## REMOVAL

1. REMOVE V-BANK COVER
2. REMOVE ENGINE UNDER COVER  
Remove the 4 bolts and engine under cover.
3. REMOVE FAN AND GENERATOR V BELT  
(See page [EM-62](#))
4. REMOVE BATTERY




### 5. REMOVE GENERATOR

- (a) Disconnect the wire harness.
  - (1) Remove the bolt and wire harness stay.
  - (2) Disconnect the connector from the generator.
  - (3) Remove the terminal cap and nut.
  - (4) Disconnect the wire harness from the terminal B.



- (b) Remove the 2 bolts and wire harness clamp bracket from the generator assy.



- (c) Remove the 2 bolts and generator.