



Power Window (Double Cab)





Power Window (Double Cab)

System Outline

The power window motor will operate when the power window SW, remote control SW, or the key-linked SW is operated.

1. Power Window SW Manual/Automatic Operation

When the ignition SW is turned ON, or during key-off operation stand-by mode, the power window can be operated by the power window SW.

2. Remote Control SW Manual/Automatic Operation

When the ignition SW is turned ON, or during key-off operation stand-by mode, the power window can be operated by the remote control SW. The front passenger, rear left, right windows can be operated according to the remote control signals from the DRIVER DOOR ECU.

3. Key-Off Operation

With all the doors closed, within 43 seconds after the ignition switch has been turned to OFF from ON, the power window can be operated. However, if the front door is opened, the power window cannot be operated.

○ : Parts Location

Code	See Page	Code	See Page	Code	See Page
B8	72	F17	76	P11	B 77
B10	B 72	J36	A 74	P12	77
B11	C 72	J37	B 74	P21	75
B12	76	J38	A 74	P22	B 77
D16	76	J39	B 74	P25	77
D17	76	J45	74	P26	77
D44	76	J50	B 74	P27	77
F13	70	J58	74	P28	77

○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1E	49	Cowl Wire and Driver Side J/B (Lower Finish Panel)
1F		
1G		
1J	49	Engine Room Main Wire and Driver Side J/B (Lower Finish Panel)
1L		
2C	45	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
2H		
3A	52	Cowl Wire and Sub J/B No.3 (Upper the Accelerator Pedal)
3D		
4A	54	Cowl Wire and Sub J/B No.4 (Upper the Accelerator Pedal)
4C		

□ : Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA4	92	Engine Room Main Wire and Cowl Wire (Left Kick Panel)
IB5	92	Front Door LH Wire and Cowl Wire (Left Kick Panel)
IF5	93	Front Door RH Wire and Cowl Wire (Right Kick Panel)
IF6		
IK1	93	Floor Wire and Cowl Wire (Right Kick Panel)
IK2		
BL1	94	Rear Door No.1 Wire LH and Floor No.2 Wire (Left Side of Center Pillar)
BM1	94	Rear Door No.1 Wire RH and Floor Wire (Right Side of Center Pillar)

▽ : Ground Points

Code	See Page	Ground Points Location
IN	92	Right Kick Panel
IO	92	Left Kick Panel
BQ	94	Left Side of Center Pillar

