

INSTALLATION

1. INSTALL DIFFERENTIAL CARRIER ASSEMBLY

- (a) Install a new gasket.
- (b) Install the differential carrier assembly with the 10 washers and nuts.

NOTICE:

Be careful not to damage the installation surface.

Torque: 73 N·m (740 kgf·cm, 54 ft·lbf)

2. CONNECT REAR PROPELLER SHAFT

2WD: See page [PR-8](#)

4WD: See page [PR-15](#)

3. INSTALL REAR AXLE SHAFTS (See page [SA-98](#))

4. FILL DIFFERENTIAL WITH HYPOID GEAR OIL (See page [SA-101](#))