


## INSPECTION

### 1. INSPECT WASHER NOZZLE

- (a) While operating the washer, check whether the upper point where the washer fluid hits the windshield and the surge area are within the range indicated by the hatched line.

A	Approx. 150 mm (5.90 in.)
B	Approx. 50 mm (1.97 in.)
C	Approx. 312.3 mm (12.295 in.)
D	Approx. 299.2 mm (11.780 in.)

- (b) Check if the lower point where the washer fluid hits the windshield is within the range of the wiping pattern (the area of the glass which is wiped by the wiper blades).



### 2. ADJUST WASHER NOZZLE

Using a tool like the one shown in the illustration, change the direction of the nozzle hole to adjust the point where washer fluid hits the windshield.