


## INSTALLATION

### 1. INSTALL FUEL PRESSURE REGULATOR

- (a) Apply a light coat of gasoline to a new O-ring, and install it to the pressure regulator.
- (b) While turning the pressure regulator left and right, install it to the delivery pipe.
- (c) Install the pressure regulator with the 2 bolts.  
**Torque: 7.5 N·m (76 kgf·cm, 66 in.-lbf)**



- (d) Connect the vacuum hose to intake air resonator.
  - (e) Connect the fuel return hose to the pressure regulator.
- ### 2. CHECK FOR FUEL LEAKS (See page [SF-1](#))