



DISASSEMBLY

1. REMOVE HEATER RADIATOR

- (a) Remove the 3 screws and 3 clamps.
- (b) Pull out the heater radiator.
- (c) Remove the 2 screws and 2 clips, then disconnect the heater radiator pipes.

2. REMOVE AIR VENT DUCT

Remove the 2 screws and duct.