



# STEERING COLUMN (Standard Cab, Access Cab) COMPONENTS

SR1KG-02

## Non-tilt steering column (M/T)




## Non-tilt steering column (A/T)




N·m (kgf·cm, ft·lbf) : Specified torque

## Tilt steering column (M/T)




N·m (kgf·cm, ft·lbf) : Specified torque

## Tilt steering column (A/T)



N-m (kgf-cm, ft-lbf) : Specified torque

## Non-tilt steering column




N-m (kgf-cm, ft-lbf) : Specified torque

◆ Non-reusable part

N ← Molybdenum disulfide lithium base grease

## Tilt steering column



N·m (kgf·cm, ft·lbf) : Specified torque

◆ Non-reusable part

← Molybdenum disulfide lithium base grease