

## REMOVAL

1. REMOVE MASTER CYLINDER (See page [BR-20](#))
2. DISCONNECT VACUUM HOSE FROM BRAKE BOOSTER
3. REMOVE SCUFF PLATE LH, COWL SIDE TRIM LH, LOWER FINISH PANEL AND NO. 2 HEATER TO REGISTER DUCT (See page [BO-111](#))
4. REMOVE PEDAL RETURN SPRING
5. REMOVE CLIP AND CLEVIS PIN
6. REMOVE BRAKE BOOSTER
  - (a) Remove the 4 nuts and clevis.
  - (b) Pull out the brake booster and gasket.
  - (c) Remove the 2 stopper rings, brake booster bracket and gasket from the brake booster.

