

INSTALLATION

HINT:

The procedures listed below are for the LH side.

1. INSTALL FRONT SEAT

- (a) Mount the front seat to the vehicle.

NOTICE:

Be careful not to damage the vehicle body.

- (b) w/ Side airbag:
Connect the airbag connector.
- (c) Connect the connectors.
- (d) Slide the front seat to the rearmost position.
- (e) Tighten the bolts on the front side temporarily, starting from the bolt on the inner side.
- (f) Tighten them completely.
Torque: 37 N·m (380 kgf·cm, 27 ft·lbf)
- (g) Slide the front seat to the foremost position.
- (h) Tighten the bolts on the rear side temporarily, starting from the bolt on the inner side.
- (i) Tighten them completely.
Torque: 37 N·m (380 kgf·cm, 27 ft·lbf)

2. INSTALL SEAT TRACK COVERS

3. CONNECT CABLE TO NEGATIVE BATTERY TERMINAL

4. Passenger's seat:

PERFORM PASSENGER OCCUPANT CLASSIFICATION SYSTEM ZERO POINT CALIBRATION
(See page [DI-1829](#))