


# STOP LIGHT SYSTEM LOCATION

BE2LT-01


## Double Cab

Instrument Panel J/B

● STOP Fuse



High-mounted Stop Light




Rear Combination Light

● Stop Light


Except Double Cab

Driver Side J/B  
● STOP Fuse



Stop Light Switch

High-mounted Stop Light



Rear Combination Light  
● Stop Light