

REPLACEMENT

1. REMOVE THROTTLE BODY COVER
2. REMOVE INTAKE MANIFOLD ASSEMBLY
(See page [EM-36](#))
3. REMOVE VVT SENSOR
 - (a) Disconnect the VVT sensor connector.
 - (b) Remove the bolt and VVT sensor.
4. INSTALL VVT SENSOR
 - (a) Attach a new VVT sensor to the cylinder head.
 - (b) Install the VVT sensor with the bolt.
Torque: 6.5 N·m (65 kgf·cm, 58 in.·lbf)
5. REINSTALL INTAKE MANIFOLD ASSEMBLY
(See page [EM-60](#))
6. REINSTALL THROTTLE BODY COVER