


## REASSEMBLY


1. INSTALL REAR DOOR WEATHERSTRIP NO. 2
  2. INSTALL REAR DOOR WEATHERSTRIP
  3. INSTALL REAR DOOR OUTSIDE HANDLE
- Torque: 5.5 N·m (56 kgf·cm, 49 in.-lbf)



### 4. INSTALL REAR DOOR LOCK

#### HINT:

Apply MP grease to the sliding and rotating parts of the front door lock.



- (a) Using a torx® socket wrench, install the rear door lock with the 3 torx® screws.

#### **Torx® socket wrench:**

**T30 (Part No. 09042-00010 or locally manufactured tool)**


**Torque: 5 N·m (51 kgf·cm, 44 in.-lbf)**

#### HINT:

Apply adhesive to the 3 screws.

**Adhesive: Part No. 08833-00070, THREE BOND 1324 or equivalent.**

- (b) Connect the connector.
- (c) Install the clamp.
- (d) Connect the 2 control cables to the clamp.




### 5. INSTALL REAR DOOR POWER WINDOW REGULATOR

#### HINT:

Apply MP grease to the rear door power window regulator.

- (a) Install the power window regulator motor to the rear door power window regulator with the 3 screws.




- (b) Install the rear door power window regulator with the 6 bolts.

**Torque: 8.0 N·m (82 kgf·cm, 71 in.-lbf)**

**HINT:**

Tighten the 6 bolts in the order shown in the illustration.

- (c) Connect the connector.



- 6. INSTALL REAR DOOR WINDOW FRAME REAR LOWER**


- 7. INSTALL REAR DOOR BELT MOULDING**

- 8. INSTALL REAR DOOR WINDOW FRAME MOULDING UPPER**

- 9. INSTALL REAR DOOR GLASS RUN**

- 10. INSTALL REAR DOOR GLASS**

**Torque: 8.0 N·m (82 kgf·cm, 71 in.-lbf)**



- 11. INSTALL REAR DOOR SERVICE HOLE COVER**

- (a) Install the service hole cover.



**HINT:**

- When installing the service hole cover, pull out the cables and connectors through the service hole cover.
- There should be no wrinkles or folds after attaching the service hole cover.
- After attaching the service hole cover, confirm the sealing condition.

- (b) Connect the clamps and connector.

- 12. INSTALL REAR DOOR INSIDE HANDLE**

- (a) Connect the 2 cables to the inside handle.



- (b) Slide the inside handle forward to install it.

- (c) Install the screw.

- 13. INSTALL SPEAKER**

- 14. INSTALL REAR DOOR TRIM PANEL**

- 15. INSTALL REAR ARMREST BACE PANEL UPPER**

- 16. INSTALL COURTESY LIGHT**

- 17. INSTALL DOOR INSIDE BEZEL**