



REMOVAL

1. **REMOVE FRONT WHEEL**
Torque: 113 N·m (1,150 kgf·cm, 83 ft·lbf)
2. **DISCONNECT SPEED SENSOR CONNECTOR**
3. **REMOVE SPEED SENSOR**
 - (a) Remove the 2 clips and 3 clamp bolts holding the sensor harness from the frame, upper arm and steering knuckle.
Torque: 8.0 N·m (82 kgf·cm, 71 in·lbf)
 - (b) Remove the bolt and speed sensor from the steering knuckle.
Torque: 8.0 N·m (82 kgf·cm, 71 in·lbf)