



INSPECTION

1. INSPECT RSCA OFF INDICATOR LIGHT

- Turn the ignition switch to the ON position.
- Check that the RSCA OFF indicator light goes off after it comes on for 3 seconds.
- Check that the RSCA OFF indicator light comes on after pressing the RSCA OFF switch for approx. 2 seconds.

2. INSPECT RSCA OFF SWITCH CONTINUITY

- Inspect the continuity between each terminal.

Switch Position	Tester Connection	Specified Condition
OFF	SW (1) ↔ E (4)	No Continuity
Hold ON	SW (1) ↔ E (4)	Continuity

If continuity is not as specified, replace the RSCA OFF switch.

