





Navigation and Audio System with RSES (Double Cab)







Navigation and Audio System with RSES (Double Cab)





Navigation and Audio System with RSES (Double Cab)





Navigation and Audio System with RSES (Double Cab)

: Parts Location

Code	See Page	Code	See Page	Code	See Page
C16	72	J54	74	R28	B 75
D33	73	J60	76	R29	C 75
F15	76	P5	A 75	R30	D 75
F16	76	R6	B 77	R31	E 75
H11	73	R7	B 77	S23	A 77
H12	73	R17	A 75	S24	B 77
J40	A 74	R18	B 75	T7	B 77
J41	B 74	R19	C 75	T8	B 77
J42	A 74	R21	77	V10	75
J43	B 74	R27	A 75		

: Relay Blocks

Code	See Page	Relay Blocks (Relay Block Location)
2	42	Engine Room R/B No.2 (Engine Compartment Left)

: Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1F	49	Cowl Wire and Driver Side J/B (Lower Finish Panel)
2A	45	Engine Room Main Wire and Engine Room J/B (Engine Compartment Left)
2B		
3A	52	Cowl Wire and Sub J/B No.3 (Upper the Accelerator Pedal)
3B		
4A	54	Cowl Wire and Sub J/B No.4 (Upper the Accelerator Pedal)
4C		
4D		

: Connector Joining Wire Harness and Wire Harness

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
IA4	92	Engine Room Main Wire and Cowl Wire (Left Kick Panel)
IB5	92	Front Door LH Wire and Cowl Wire (Left Kick Panel)
IC3	92	Cowl Wire and Roof Wire (Left Side of Instrument Panel)
IF6	93	Front Door RH Wire and Cowl Wire (Right Kick Panel)
IK1	93	Floor Wire and Cowl Wire (Right Kick Panel)
IL1	93	Floor No.2 Wire and Cowl Wire (Instrument Panel Brace RH)
IL2	92	Floor No.2 Wire and Cowl Wire (Right Kick Panel)
IM3	92	Console Box Wire and Cowl Wire (Rear Console)
IM4		
BL1	94	Rear Door No.1 Wire LH and Floor No.2 Wire (Left Side of Center Pillar)
BM1	94	Rear Door No.1 Wire RH and Floor Wire (Right Side of Center Pillar)

: Ground Points

Code	See Page	Ground Points Location
IP	92	Instrument Panel Brace LH
BR	94	Back Panel Left

