


## ADJUSTMENT

### 1. ADJUST DOOR IN FORWARD/ REARWARD AND VERTICAL DIRECTIONS


- Remove the front and rear door scuff plates.
- Remove the center pillar lower garnish.
- Remove the front seat outer belt (see page [BO-133](#)).
- Loosen the body side hinge nuts to adjust.  
**Torque: 23 N·m (230 kgf-cm, 17 ft-lbf)**
- Install the front seat outer belt and center pillar lower garnish (see page [BO-133](#)).
- Install the front and rear door scuff plates.



### 2. ADJUST DOOR IN LEFT/RIGHT AND VERTICAL DIRECTIONS

Loosen the door side hinge bolts to adjust.

**Torque: 23 N·m (230 kgf-cm, 17 ft-lbf)**



### 3. ADJUST DOOR LOCK STRIKER

- Check that the door fit and door lock linkages are adjusted correctly.
- Loosen the striker mounting screws to adjust.  
**Torque: 23 N·m (230 kgf-cm, 17 ft-lbf)**
- Using a plastic hammer, tap the striker to adjust it.