


REMOVAL

1. DRAIN ENGINE COOLANT
2. REMOVE DRIVE BELT
(See page [CH-7](#) and [CH-19](#))
3. REMOVE LH NO.3 TIMING BELT COVER
(See page [EM-16](#))



4. REMOVE CAMSHAFT POSITION SENSOR

Remove the bolt, stud bolt and camshaft position sensor.