


REPLACEMENT


1. REPLACE BUSHINGS

- (a) Using a saw, cut the both bushing tabs as shown in the illustration.




- (b) Using SST and a press, press out the both inner tubes and rubber parts of the bushings.

SST 09950-60010 (09951-00350)
09950-70010 (09951-07150)




- (c) Using a chisel and hammer, tap out the outer tubes.




- (d) Using SST and a press, install 2 new bushings.

SST 09710-28012 (09710-07062),
09710-30041 (09710-03211)




2. REPLACE LEAF SPRING

- (a) Bend to open the spring clips.
Using a chisel and hammer, pry up the 2 spring clips.
- (b) Remove the center bolt and nut.
Hold the spring near the spring center bolt in a vise and remove the center bolt and nut.



- (c) Replace the spring clip.
- (1) Drill off the head of the rivet and drive it out.
 - (2) Install a new rivet into the holes of the leaf spring and clip. Then rivet with a press.
- (d) Install the spring center bolt and nut.
- (1) Align the leaf spring holes and secure the leaves with a vise.
 - (2) Install the spring center bolt and nut.

Torque: 44 N·m (450 kgf-cm, 33 ft-lbf)



- (e) Bend the spring clips.
- Using a hammer, bend the spring clips into the position.