


ADJUSTMENT

ADJUST SLIDING ROOF GLASS IN CLEARANCE

- (a) When the front or rear/left or right alignment is not correct, remove the drive gear and sliding roof glass, then adjust the drive cable.



NOTICE:

Remove the drive gear with the sliding roof fully closed.

- (b) Adjust by sliding the cable forward or rearward or rearward to align the 2 marks as shown.
- (c) Install the driving gear and sliding roof glass.