



REMOVAL

1. **REMOVE CENTER CLUSTER INTEGRATION PANEL**
 - (a) Remove the 3 heater control knobs.
 - (b) Remove the 5 screws.
 - (c) Remove the integration control panel by pulling the portions indicated by arrows in the illustration.
 - (d) Disconnect the connector.
2. **REMOVE LOWER LH FINISH PANEL**
3. **REMOVE HEATER TO REGISTER DUCT NO. 2**
4. **REMOVE GLOVE COMPARTMENT DOOR**
5. **REMOVE LOWER NO. 2 FINISH PANEL**
6. **REMOVE HEATER TO REGISTER DUCT NO. 4**
(See page [BO-111](#))
7. **DISCONNECT HEATER CONTROL CABLES**



8. REMOVE HEATER CONTROL ASSEMBLY

Remove the heater control assembly, then disconnect the connectors.