


## REMOVAL

### REMOVE REAR SEAT

- (a) Release the rear seat lock and swing the seat cushions up.



- (b) Remove the 4 bolts.  
(c) Lift up the rear seat and remove it.