


# Tire Pressure Warning System (Double Cab)

\* 1 : w/ VSC  
\* 2 : w/o VSC



## System Outline

The air pressure sensor installed in the tire wheel detects the tire air pressure and transmits signals to the vehicle side receiver. When the detected tire air pressure is below a specified level, the warning light in the combination meter comes on to inform the driver.

Press the tire pressure warning standardization SW for 3 seconds with the ignition SW at ON position after the tire pressure is adjusted to the specified value. It will lead the tire pressure monitor ECU to control and warn the pressure according to the specified value.

Warnings when the tire pressure is low

\* When the tire air pressure is below a specified level, the warning light in the combination meter comes on.

## ○ : Parts Location

Code		See Page	Code		See Page	Code		See Page
C11	A	72	J43	B	74	T17		75
C12	B	72	J45		74	T18		77
D6		73	J49	A	74			
J42	A	74	T16		75			

## ○ : Junction Block and Wire Harness Connector

Code	See Page	Junction Block and Wire Harness (Connector Location)
1D	49	Cowl Wire and Driver Side J/B (Lower Finish Panel)
1F		
1H		
3A	52	Cowl Wire and Sub J/B No.3 (Upper the Accelerator Pedal)
3B		
3C		
3D		
3E		

## ▽ : Ground Points

Code	See Page	Ground Points Location
IO	92	Left Kick Panel