


REMOVAL

1. **REMOVE TRANSMISSION FROM ENGINE**
(See page [MT-3](#))
2. **REMOVE CLUTCH COVER AND CLUTCH DISC**
 - (a) Put matchmarks on the flywheel and clutch cover.
 - (b) Loosen each set bolt one turn at a time until spring tension is released.
 - (c) Remove the set bolts, and pull off the clutch cover with the clutch disc.

NOTICE:

Do not drop the clutch disc.



3. **REMOVE BOOT, CLUTCH RELEASE BEARING AND CLUTCH RELEASE FORK FROM TRANSMISSION**
 - (a) Remove the boot and release bearing together with the fork.
 - (b) Remove the clip from the release bearing.