

## REMOVAL

1. REMOVE V-BANK COVER
2. REMOVE AIR CLEANER (See page [EM-62](#))
3. REMOVE INTAKE AIR SURGE TANK (See page [EM-62](#))
4. REMOVE FUEL DELIVERY PIPE
5. REMOVE CAMSHAFT TIMNG OIL CONTROL VALVE
  - (a) Disconnect the 2 oil control valve connectors.
  - (b) Remove the 2 bolts and 2 camshaft timing oil control valves.