

## EXTENSION HOUSING OIL SEAL (A750E)

AT13L-01

### ON-VEHICLE REPAIR

#### 1. DRAIN AUTOMATIC TRANSMISSION FLUID

- (a) Remove the drain plug and gasket, and drain the ATF.
- (b) Install a new gasket and the drain plug.

**Torque: 20 N·m (204 kgf-cm, 15 ft-lbf)**

#### 2. REMOVE PROPELLER SHAFT (See page [PR-3](#))


#### 3. REMOVE REAR OIL SEAL

##### NOTICE:

**Clean the extension housing before removing the oil seal.**

Using SST, remove the oil seal.

SST 09308-10010



#### 4. INSTALL OIL SEAL

- (a) Using SST and a hammer, carefully drive a new oil seal in until it stops.

SST 09325-40010

- (b) Coat the lip of the oil seal with MP grease.

#### 5. INSTALL PROPELLER SHAFT (See page [PR-8](#))

#### 6. FILL TRANSMISSION (See page [AT-4](#))

