



# KNOCK SENSOR REMOVAL


1. REMOVE CYLINDER HEAD (See page [EM-62](#))



2. DISCONNECT HEATER WATER INLET HOSE



3. REMOVE WATER OUTLET PIPE NO.1
  - (a) Remove the 4 wire harness clamps.
  - (b) Remove the 3 bolts and water outlet pipe.



4. REMOVE KNOCK SENSOR
  - (a) Disconnect the 2 knock sensor connectors.
  - (b) Remove the 2 bolts and 2 knock sensors.