

REMOVAL

NOTICE:


- If the wiring connector of the SRS is disconnected with the ignition switch in the ON position, DTCs will be recorded.
- Never use SRS parts from another vehicle. When replacing the parts, replace them with new ones.
- Never reuse an occupant classification sensor if a air-bag has previously deployed in a collision.

1. PRECAUTION (SEE PAGE RS-1 AND RS-3)
2. DISCONNECT CABLE FROM NEGATIVE BATTERY TERMINAL

Wait for 90 seconds after disconnecting the cable to prevent the airbag working.

3. Bench type:
REMOVE FRONT SEAT (SEE PAGE BO-166)
4. Bench type:
REMOVE OCCUPANT CLASSIFICATION ECU
(SEE PAGE RS-154)
5. Bench type:
REMOVE SEAT HINGE COVER LH AND RH
(SEE PAGE BO-167)
6. Bench type:
REMOVE SEATBACK ASSEMBLY
(SEE PAGE BO-167)
7. Bench type:
REMOVE 2 SEAT TRACK LOWER REAR BRACKETS
(SEE PAGE BO-167)
8. Bench type:
REMOVE LH OUTER TRACK ASSEMBLY
(SEE PAGE BO-167)
9. Bench type:
REMOVE RH OUTER TRACK ASSEMBLY
(SEE PAGE BO-167)
10. Bench type:
REMOVE SEAT TRACK HANDLE LH
(SEE PAGE BO-167)
11. Bench type:
REMOVE SEAT TRACK HANDLE RH
(SEE PAGE BO-167)
12. Bench type:
REMOVE SEAT CUSHION SUB-ASSEMBLY
(SEE PAGE BO-167)
13. Split type (Passenger's Side):
REMOVE SEAT TRACK COVER (SEE PAGE BO-188)
14. Split type (Passenger's Side):
REMOVE FRONT SEAT ASSEMBLY RH
(SEE PAGE BO-188)

15. Split type (Passenger's Side):
REMOVE OCCUPANT CLASSIFICATION ECU
(SEE PAGE RS-154)
16. Split type (Passenger's Side):
REMOVE SEAT LEG INNER COVER
(SEE PAGE BO-189)
17. Split type (Passenger's Side):
REMOVE RECLINING ADJUSTER RELEASE HANDLE
(SEE PAGE BO-189)
18. Split type (Passenger's Side):
REMOVE RH SEAT CUSHION SHIELD
(SEE PAGE BO-189)
19. Split type (Passenger's Side):
REMOVE SEAT CUSHION LOWER SHIELD
(SEE PAGE BO-189)
20. Split type (Passenger's Side):
REMOVE SEATBACK ASSEMBLY
(SEE PAGE BO-189)
21. Split type (Passenger's Side):
REMOVE RH CENTER SEAT HINGE COVER
(SEE PAGE BO-189)
22. Split type (Passenger's Side):
REMOVE RH SEAT CUSHION INNER SHIELD AND
SEAT CUSHION COVER (SEE PAGE BO-189)
23. Split type (Passenger's Side):
REMOVE SEAT HINGE COVER (SEE PAGE BO-189)
24. Split type (Passenger's Side):
REMOVE OUTER SEAT TRACK LOWER FRONT AND
REAR BRACKET (SEE PAGE BO-189)
25. Split type (Passenger's Side):
REMOVE INNER SEAT TRACK LOWER FRONT AND
REAR BRACKET (SEE PAGE BO-189)
26. Split type (Passenger's Side):
REMOVE OUTER SEAT TRACK (SEE PAGE BO-189)
27. Split type (Passenger's Side):
REMOVE INNER SEAT TRACK (SEE PAGE BO-189)
28. Split type (Passenger's Side):
REMOVE SEAT CUSHION SUB-ASSEMBLY
(SEE PAGE BO-189)



29. REMOVE OCCUPANT CLASSIFICATION SENSOR
 - (a) Disconnect the connector from the occupant classification sensor.
 - (b) Cut the band clamp from the seat cushion frame.
 - (c) Disengage the clamps from the seat cushion frame.
 - (d) Remove the 2 clips and the occupant classification sensor.