

# SUPPLEMENTAL RESTRAINT SYSTEM

## TORQUE SPECIFICATION

SS08D-04

Part tightened	N·m	kgf·cm	ft·lbf
STEERING WHEEL PAD AND SPIRAL CABLE			
Steering wheel set nut	50	510	37
Steering wheel pad set screw (Torx® screw)	8.8	90	78 in·lbf
FRONT PASSENGER AIRBAG ASSEMBLY			
Front passenger airbag assembly x Instrument panel	5.0	51	44 in·lbf
Front passenger airbag assembly x Instrument panel	20	204	15
SIDE AIRBAG ASSEMBLY (Power Adjuster Type)			
Front seat x Body	37	377	27
Front seat inner belt x Front seat	42	428	31
Seatback cover bracket x Seatback frame	5.5	56	49 in·lbf
Armrest assembly x Front seat	37	377	27
SIDE AIRBAG ASSEMBLY (Manual Adjuster Type)			
Front seat x Body	37	377	27
Front seat inner belt x Front seat	42	428	31
Seatback cover bracket x Seatback frame	5.5	56	49 in·lbf
Armrest assembly x Front seat	37	377	27
SIDE AIRBAG ASSEMBLY (Passenger Side of Split Type)			
Front seat x Body	37	377	27
Front seat center belt x Front seat	42	428	31
Seatback cover bracket x Seatback frame	5.5	56	49 in·lbf
Armrest assembly x Front seat	20	204	15
CURTAIN SHIELD AIRBAG ASSEMBLY			
Curtain shield airbag assembly x Body	9.8	100	7
AIRBAG SENSOR ASSEMBLY			
Airbag sensor assembly x Body	17.5	179	13
FRONT AIRBAG SENSOR			
Front airbag sensor x Body	17.5	179	13
SIDE AIRBAG SENSOR ASSEMBLY			
Side airbag sensor assembly x Body	17.5	179	13
CURTAIN SHIELD AIRBAG SENSOR ASSEMBLY			
Curtain shield airbag sensor assembly x Body	17.5	179	13
SEAT POSITION SENSOR ASSEMBLY (For Driver Seat)			
Seat position sensor assembly x Front seat	8.0	82	71 in·lbf
SEAT POSITION SENSOR (For Front Passenger Seat)			
Seat position sensor x Front seat	8.0	82	71 in·lbf
OCCUPANT CLASSIFICATION ECU (Except Separate Seat)			
Occupant classification ECU x Front seat	3.0	30	27 in·lbf
SEAT BELT TENSION SENSOR (Except Separate Seat)			
Front seat inner belt RH x Front seat (Split seat)	42	430	32
Front seat outer belt floor anchor RH x Body (Bench seat)	42	430	32