


## BLOWER MOTOR INSPECTION

AC3RY-02

### 1. REMOVE BLOWER MOTOR


- (a) Double cab:  
Remove the 2 screws and motor cover.
- (b) Disconnect the connector.
- (c) Remove the 3 screws and motor.



### 2. Standard cab, Access cab: INSPECT BLOWER MOTOR OPERATION

Connect the positive (+) lead from the battery to terminal 1 and the negative (-) lead to terminal 2, then check that the motor operates smoothly.


If operation is not as specified, replace the blower motor.



### 3. Double cab: INSPECT BLOWER MOTOR OPERATION

Connect the positive (+) lead from the battery to terminal 1 and the negative (-) lead to terminal 2, then check that the motor operates smoothly.

If operation is not as specified, replace the blower motor.



### 4. INSTALL BLOWER MOTOR

- (a) Install the motor with the 3 screws.
- (b) Connect the connector.