

## INSPECTION

### INSPECT RECLINING LOCK POSITION SLIPPING OFF

When reclining the seat, check that the RH and LH rear seat reclining adjusters are released at the same time.

#### HINT:

When the reclining lock position slips off, disassemble the seat to adjust the position.