

# ENGINE (2UZ-FE)

D1DQQ-01

## PRECAUTION

**NOTICE:**

Perform the RESET MEMORY (AT initialization) when replacing the automatic transmission assembly, engine assembly or ECM (See page [DI-1126](#)).

**HINT:**

Initialization can not be completed by only removing the battery.