


REPLACEMENT

REPLACE TIMING CHAIN COVER OIL SEAL

(a) Using a screwdriver, pry out the oil seal.

NOTICE:

Be careful not to damage the oil pump assembly. Wrap the tip of the screwdriver with tape.



(b) Using SST and a hammer, tap in a new oil seal until its surface is flush with the timing chain cover edge.

SST 09226-10010

(c) Apply MP grease to the oil seal lip.