

DISASSEMBLY

CAUTION:

Wear safety gloves, because the sharp edges and surfaces of the seat frame may cause injury to the hands.

HINT:


- Tape the screwdriver tip before using it to remove the parts.
- A bolt without a torque specification is shown in the standard bolt chart (see page [SS-2](#)).

1. REMOVE HEADREST

Remove the 2 headrests.


2. REMOVE RECLINING ADJUSTER RELEASE HANDLE

Remove the screw and release handle.




3. REMOVE NO. 1 RECLINING COVER LH

- Unzip the seat cushion cover.
- Remove the screw and No. 1 rear seat reclining cover.




4. REMOVE NO. 1 RECLINING COVER RH

- Unzip the seat cushion cover.
- Remove the screw and No. 1 rear seat reclining cover.





5. REMOVE SEAT CUSHION UNDER COVER (LH AND RH)

- Remove the 2 screws and 2 seat cushion under covers.




- (b) Using a 5 mm hexagon wrench, remove the bolt and cushion.
 - (c) Remove the 10 screws and seat cushion under cover.
- 6. REMOVE FOLD SEAT LOCK CONTROL CABLE NO. 1**
- (a) Tilt the seat forward.
 - (b) Remove the clamp and fold seat lock control cable as shown in the illustration.




7. REMOVE SEATBACK ASSEMBLY

- (a) As shown in the illustration, disengage the hook and open the seatback cover.



- (b) Remove the reclining connecting wire of the LH side edge.




- (c) Remove the reclining connecting wire of the RH side edge.

- (d) Remove the 4 bolts and the seatback assembly.

Torque: 43 N·m (440 kgf-cm, 32 ft-lbf)

8. REMOVE ARMREST



9. REMOVE SEATBACK COVER

- (a) Using a screwdriver, disengage the 4 claws and remove the rear seat shoulder belt cover.


HINT:

Tape the screwdriver tip before use.

- (b) Remove the 4 headrest supports.
- (c) Disengage the hooks, and remove the seatback frame from the seatback cover with pad.
- (d) Remove the seatback cover from the seatback pad.
- (e) Remove the hog rings and seatback cover.

HINT:

At the time of reassembly, take as much care as possible to minimize wrinkles when installing hog rings.





10. REMOVE REAR SEATBACK BOARD

Using a clip remover, remove the 6 clips and seatback board.

11. REMOVE SEAT ADJUSTER CONTROL CABLE

Remove the 2 clamps and seat adjuster control cable.

**12. REMOVE REAR SEAT OUTER BELT**

- (a) Remove the 2 bolts and rear seat shoulder belt guide.

Torque: 43 N·m (440 kgf-cm, 32 ft-lbf)

- (b) Remove the nut, rear seat outer belt.

Torque: 43 N·m (440 kgf-cm, 32 ft-lbf)

13. REMOVE SEAT CUSHION COVER

- (a) Remove the seat cushion cover with pad from the seat cushion frame.


- (b) Remove the seat cushion cover from the seat cushion pad.

HINT:

At the time of reassembly, take as much care as possible to minimize wrinkles when installing hog rings.

14. REMOVE REAR NO. 1 SEAT ADJUSTER

- (a) Remove the 2 bolts and rear No. 1 seat outer adjuster.
Torque: 43 N·m (440 kgf·cm, 32 ft·lbf)
- (b) Remove the 2 bolts and rear No. 1 seat inner adjuster.
Torque: 43 N·m (440 kgf·cm, 32 ft·lbf)
- (c) Remove the 4 screws and 2 hinges covers from the rear No. 1 seat outer and inner adjusters.
- (d) Remove the 2 screws and 2 reclining inner covers from the rear No. 1 seat outer and inner adjusters.

**15. REMOVE REAR SEAT STAY**


Remove the 2 bolts and rear seat stay.

16. REMOVE REAR SEAT CUSHION HINGE (LH AND RH)

- (a) Using a screwdriver, remove the spring nut and E-rings.
- (b) Remove the 2 hinge pins, 2 cushion spacers, 2 cushion support springs and 2 rear seat cushion hinges.

17. REMOVE LH REAR SEAT LOCK

Unfasten the bolt, then remove the inner belt and LH rear seat lock.

**18. REMOVE RH REAR SEAT LOCK**

- (a) Remove the screw and rear seat lock cover.
- (b) Remove the bolt, seat belt anchor and inner belt.
Torque: 43 N·m (440 kgf·cm, 32 ft·lbf)
- (c) Remove the RH rear seat lock.