

INSTALLATION

1. INSTALL VVT SENSOR

(a) LH bank side VVT sensor.



(1) Apply a light coat of engine oil to an O-ring of the VVT sensor.

(2) Install the VVT sensor with the bolt.

Torque: 9.0 N·m (92 kgf·cm, 80 in.·lbf)

(3) Connect the VVT sensor connector.

(4) Connect the water by-pass hose No. 4 and No. 5.



(b) RH bank side VVT sensor.

(1) Apply a light coat of engine oil to an O-ring of the VVT sensor.

(2) Install the VVT sensor with the bolt.

Torque: 9.0 N·m (92 kgf·cm, 80 in.·lbf)

(3) Connect the VVT sensor connector.

2. INSTALL AIR CLEANER (See page [EM-89](#))

3. INSTALL V-BANK COVER

4. ADD ENGINE COOLANT