

REPLACEMENT

REPLACEMENT REQUIREMENTS

In the following cases, replace the seat position sensor with a new one:

- The seat position sensor has been found to be faulty in troubleshooting.
- The seat position sensor has been dropped.

CAUTION:

For removal and installation procedures of the seat position sensor, see page [RS-145](#) and [RS-149](#). Be sure to follow the correct procedure.